

## Temperature sensor type K (NiCrNi)

---

### PAN PUNKTFÜHLER-SET

Temperature point sensor, K thermocouple  $-50^{\circ}$  -  $+400^{\circ}\text{C}$  +  
adapter plug for connection to multimeter

Temperature point sensor, K thermocouple  $-50^{\circ}$  -  $+400^{\circ}\text{C}$  +  
adapter plug for connection to multimeter

