

Fuses

Fuses

- **SI 0,25A600V5X20** - Fuse F 0,25A 600V 5x20mm
for PAN 118 new, Minimeter
- **SI 0,25A600V6X30** - Fuse F 0,25A 600V 6 x 30 mm
for PAN 5500, PAN ISOMETER
- **SI 0,2A250V5X20** - Fuse F 0,2A 250V 5 x 20mm
for PAN 184 old
- **SI 0,2A400V5X20** - Fuse FF 0,2A 400V 5x20 mm
- **SI 0,2A600V5X20** - Fuse F 0,2A 600V 5 x 20 mm
for PAN 118 new, 184 old , Kabelfinder, LAN1, Micro, Mini, Profi
old
- **SI 0,315A400V5X20** - Fuse FF 0,315A 400V 5x20 mm
- **SI 0,4A1000V6,3X32** - Fuse F 0,4A 1000V 6,3x32 mm
for PAN 185 new
- **SI 0,5A1000V6,3X32** - Fuse FF 0,5A 1000V 6,3x32mm
for PAN 186 old, 188 old, 189USB, Multicar, Leitungsfinder
- **SI 0,5A660V5X20**- Fuse FF 0,5A AC 660V 5 x 20 mm
for PAN 185 old
- **SI 0,6A1000V6,3X32** - Fuse F 0,6A 1000V 6,3x32mm
for PAN 184, 186, 188 new
- **SI 0,6A600V5X20** - Fuse F 0,6A 600V 5x20mm
for PAN Profimeter new
- **SI 0,8A1000V6,3X32** - Fuse FF 0,8A 1000V 6,3 x 32mm
for PAN 187LCR, OSCIMETER
- **SI 10A1000V10X38** - Fuse 10A 1000V 10 x 38mm
for PAN 186 ALT, 188 ALT, 189USB, OSCIMETER
- **SI 10A1000V6,3X32** - Fuse F 10A 1000V 6,3x32mm
for PAN 184, 185, 186, 188 new
- **SI 10A250V6,35X25** - Fuse F 10A 250V 6,35 x 25mm
for PAN 184 old
- **SI 10A600V5X20** - Fuse F 10A 600V 5 x 20mm
for PAN Minimeter old+new, PAN Profimeter old+new
- **SI 10A600V6,3X32** - Fuse F 10A 600V 6,3 x 32,0mm
for PAN 185 old, Multicar
- **SI 10A600V6X25** - Fuse F 10A 600V 6 x 25 mm
for PAN 184 old
- **SI 15A600V10,3X38** - Fuse F 15A 600V AC 10,3 x 38mm
for PAN 183/ 185/ 187T/ 285/ 387 old Serie
- **SI 1A600V6X25** - Fuse F 1A 600V AC 6 x 25 mm
for PAN 70A, 70B, 70D
- **SI 20A250V6,3X32** - Fuse 20A 250V 6,3 x 32mm
for PAN Multicar
- **SI 20A250V6X25** - Fuse 20A 250V 6 x 25 mm
for PAN 184 old
- **SI 2A600V10X35** - Fuse F 2A 600V AC 10,3 x 35 mm
for PAN 183/ 185/ 187T/ 285/ 387 old series

